

Instruction for Vector Optics Veyron 3-12x44 Rifle Scope



WARNING: NEVER LOOK AT THE SUN THROUGH THE RIFLESCOPE (OR ANY OTHER OPTICAL INSTRUMENT). IT MAY PERMANENTLY DAMAGE YOUR EYES.

EYEPiece FOCUSING

The eyepiece is designed to provide a precise fast focus at certain eye relief. The eyepiece will focus faster than your eye can compensate for any inaccuracy in your adjustment.

MOUNTING

The rifle scope is installed on gun by means of a pair of weaver or dovetail mount rings. Use qualified mount with base designed to fit your particular rifle. The rifle scope shall be mounted as low as possible without touching either the barrel or the receiver. For safety reasons, allow at least 3 inches of clearance between the rifle scope and your eyes when shooting. Slide rifle scope forward or backward to acquire the proper eye relief that allows you to see full field of view. Rotate the rifle scope in the rings that the vertical crosshair is vertical and horizontal crosshair is horizontal. Then tighten all screws to fix rifle scope firmly on the rifle.

Do not over tighten the mount rings. It may lead to damage to the rifle scope and mount.

ZEROING

Veyron rifle scope features finger-adjustable audibleclick elevation and windage adjustments. Elevation is thevertical (up-and-down) adjustment, usually on the top of the rifle scope. Windage is the horizontal (left-to-right) adjustment, usually on the right of the rifle scope.

The scope feature 1/ 10 MIL windage and elevation adjustment with audible clicks, meaning that 1 click moves the point of impact 1/10 MIL at 100 yards or 1cm at 100 meters.

With the rifle scope mounted, rest the firearm onto a solid support and aim at a target 100 yards away. Slowly shoot a small 3 to 5 round test group onto your target. Adjust windage & elevation screws in the direction you want to move the bullet impact. Each click of adjustment moves the point of impact. Shoot another 3 to 5 round test group. Repeat until you are satisfied with the point of aim.

VARIABLE MAGNIFICATION ADJUSTMENTS

To change magnification, simply rotate the Power Selector Ring to achieve the designed power with index dot.

Generally speaking, lowest power to have the widest field of view for quick shots at close range. Higher power should be reserved for precise long-range shots.

SEALED, WATERPROOF AND FOGPROOF

The riflescope is nitrogen_purged to remove any vestige of internal moisture, also has O_ring to prevent the entry of dust or moisture.

MAINTENANCE

Your riflescope, though amazingly tough, is a precision instrument that deserves reasonable cautious care.

- When cleaning the lens, first blow away any dirt and dust, or use a soft lens brush. Fingerprints and lubricants can be wiped off with lens tissue, or a soft clean cotton cloth, moistened with lens cleaning fluid.
- All moving parts of the riflescope are permanently lubricated. Do not try to lubricate them.
- No maintenance is needed on the riflescope's outer surface, except to occasionally wipe off dirt or fingerprints with a soft cloth.
- Use lens covers whenever convenient.

STORAGE

Avoid storing the riflescope in hot places, such as the passenger compartments of vehicles on hot days. The high temperatures could adversely affect the lubricants and sealants. A vehicle's trunk, a gun cabinet or a closet is preferable. Never leave the riflescope where direct sunlight can enter either the objective lens.

Damage may result from the concentration (burning glass effect) of the sun's rays.

For More details please visit our website: www.vectoroptics.com

VECTOR OPTICS



MPR-4 Reticle Pattern

