

# User Manual For Paragon 8x42 Binocular



## HOW TO USE YOUR BINOCULAR:

### A.IDP ADJUSTMENT

Set the interpupillary distance by grasping the body, and bending it until you can see one circle of view. The setting for your eyes will be indicated on the IPD Scale. (Note the scale setting for later use)

### B.FOCUSING

- Close your right eye and sight an object with your left eye. Focus the binocular by rotating the center focus wheel until the image is sharp and clear.
- Open your right eye and close your left eye. Rotate the right eyepiece until the object sighted is sharp and clear (Note the setting of the diopter scale for later use)
- Both sides(eyes)are now in focus and you will need to use only the center focus wheel to focus on the other objects.

### C.RUBBER FOLD-DOWN EYECUPS

Fold down for use with eyeglasses and fold up for use without eyeglasses. They provide comfort and promote vie ease.

## HOW TO CARE FOR YOUR BINOCULAR:

A.Keep the lens covers(that come with your binocular, except compact type) on the lenses when the binocular is not in use.

B.When wiping the lenses, use the lens cloth that comes with the binocular, or a soft, lintless cloth.

C.To remove any remaining dirt or smudges, add one or two drops of isopropyl alcohol to the cloth.

D.Store you're binoculars in a moisture-free area.

## VERY IMPORTANT:

Never attempt to clean your binocular internally or try to take them apart.

## CAUTION:

Viewing the sun can cause permanent eye damage. Do not view the sun with these binoculars or even with the naked eye.